

På Dansk

- Tag bagdæksel af sender (2 stk. stjerne skruer), og frakobl batteri
- Hold stop knappen inde på fjernbetjening
- Tilkobl batteri
- Alarmen vil begynde at bippe hurtigere og hurtigere, og til sidst hyle i en tone
- Slip stop kontakten på fjernbetjeningen
- Tryk knap 1 og 2 på fjernbetjeningen
- Genstart derefter systemet, og dette er sat til "HIGH Power"
- Monter bagdæksel på sender igen (2 stk. stjerne skruer)

*På Modtagere med Antennen indbygget, må denne ikke monteres inden i en stålbox,
da dette kan afskærme signalet.*

On RXFM2 and RXFM8 you can't connect an external antenna, but you can increase transmitter power. Transmitters have 3 power level and standard are setted to medium, to set power level please on transmitter:
disconnect battery
press and keep pressed stop, plug battery acoustic alarm start beep goes faster and became continue, release stop
switch press 1+2 to high power (1 for low or 2 to medium) that's all, transmitter is now setted and power level is stored.

On receivers where antenna is integrated please don't mount receiver inside of a steel box, this will shield radio signal.